


# HUMIDIFIER-200 PINTS COMERICAL INDUSTRIAL GRADE

## —PART LIST—



ID#	Description	ID#	Description
1	Upper Fan Blade	11	Mid Pan
2	Motor	12	Lower Pan
3	Capacitor	13	Leg
4	Motor Cover	14	Fogging Head
5	Motor Support	15	Screen
6	Cord	16	Handle
7	Atomizing Screen	17	Housing
8	Disk	18	Reservoir Pan
9	Pump	19	Floater
10	Lower Fan Blade	20	Extra 3-way Fogger Cup

## —CAUTION—

- This is NOT A TOY. Don't let children play with appliance.
- If power cord its damaged, contact manufacturer for Service.
- Unplug appliance for safety during filling and cleaning. Follow instructions included for these procedures.
- Maximum water pressure: 1.2 MPa- Minimum water pressure: 0.5 MPa.

## —TROUBLESHOOTING—

### NO Fog:

Check for motor rotation. If motor is operating properly, there will be an adequate amount of water in the pan (1/4' to 1-1/4"). If the pan runs dry, the float valve may be sticking in the up position. If so, the inlet water pressure needs to be reduced. If water supply is adequate, check the tapered pump for internal calcium buld-up. Remove, inspect and clean as needed.

### Overflowing Pan:

An overfilled pan can cause poor quality fog and wetness around the unit. A leaky float valve or a float that has filled with water may be the problem. To check the float, raise it out of the water and visually inspect it. No water should be inside and it should not sink. If OK, then check for leaky valve. Turn water off and remove the fogger from the pan. Empty the pan and towel dry. Hold the float in the up position and turn on the water. If any water enters the pan while the float is in the up position, the float valve needs to be replaced.

## —MAINTENANCE—

- Regularly clean the Reservoir Pan Assembly with soap and water to remove dirt and sediment. Use liquid bleach after cleaning, to sterilize any parts if algae was present.
- Periodically remove Strainer Screen and thoroughly flush. Also check to make sure the tapered pump/fan blade assembly is free of debris.
- Once every three months, check unit for calcium build-up. If build up deposits are present, disconnect the water and take the unit outside. Pour calcium dissolving solvent (available in local hard ware stores) in pan and operate unit outside to soften and remove the deposits.
- About once a year, remove the housing to check the SST Atomizing Screen to be sure the slots are clear of mineral build-up. To clean, scrub with a calcium dissolving solvent.
- Unplug the appliance during filling and cleaning.



## THEPROTECTOR LIMITED PRODUCT WARRANTY

Please take the time to read through our Standard Terms and Conditions of the THEPROTECTOR Limited Product Warranty.

### How Long Does The Coverage Last?

The product warranty becomes effective from the date of purchase by the purchaser. Coverage terminates if you sell or otherwise transfer the product. The repair of your product under warranty will not extend the period of the warranty. Each part has its own warranty. Please check the warranty list before you place an order.

### How Do You Get Service?

Products are to be returned to THEPROTECTOR Tech Support Center under your express account. Address: 10725 Capital St. Oak Park. MI +1 248-542-1831

### What is Covered?

Normal wear and tear. We will repair or replace your product if your product is found, within the warranty period, to be defective due to defective materials or workmanship existing at the time of purchase. If any part is no longer available or out of manufacture, THEPROTECTOR will replace it with a functionally-equivalent replacement part.

### What is Not Covered?

THEPROTECTOR shall NOT be liable for costs of repair or replacement of a product incurred as a result of:

1. Accidental damage, faults caused by negligent use or care, neglect, careless operation or handling of the product which is not in accordance with the THEPROTECTOR Instruction Manuals.
2. Use of the parts not assembled or installed in accordance with the instructions of THEPROTECTOR.
3. Use of parts or accessories other than those produced or recommended by THEPROTECTOR.
4. External sources such as transit damage or weather.
5. Repairs or alterations carried out by parties other than THEPROTECTOR or its authorized agents.
6. Serial numbers defaced or missing.

THEPROTECTOR warrants the mechanical and electronic components of all THEPROTECTOR series to be free of defects in material and workmanship if used under normal operating conditions for a period from the original date of purchase. If the product shows any defects within this period and that defect is not due to user error or improper use THEPROTECTOR shall, at its discretion, either replace or repair the product using suitable new or refurbished parts. In case THEPROTECTOR decides to replace the entire product, this limited warranty shall apply to the replacement product for the remaining initial warranty period.

*THEPROTECTOR DISCLAIMS ANY AND ALL LIABILITY, INCLUDING ANY EXPRESS OR IMPLIED WARRANTIES, WHETHER ORAL OR WRITTEN, FOR SUCH THIRD PARTY HARDWARE. THE CUSTOMER ACKNOWLEDGES THAT THEPROTECTOR HAS MADE ITS BEST EFFORTS TO MATCH ITS PRODUCTS TO WORK WITH THIRD PARTY HARDWARE OR THE ABILITY TO CONNECT TO AND CONTROL THIRD PARTY HARDWARE FOR THE CUSTOMER'S INTENDED PURPOSE. THEPROTECTOR ADDITIONALLY AND SPECIFICALLY DISCLAIMS ANY AND ALL LIABILITY FOR CHANGES, ADDITIONS OR UPDATES IN ANY WAY TO A THIRD PARTY MANUFACTURES PRODUCTS.*

